

# INSTRUCTION VR6 COIL UPGRADE KIT

[www.gooze.com](http://www.gooze.com)



1: REMOVE THE OLD COIL



2: REMOVE THE OLD COIL PACK



3: CUT THE 4 CONNECTORS



4: INSTALL COIL & MODULE ON BRACKET



5: INSTALL THE WIRES AS ABOVE



6: CHECK THAT WIRES DOESN'T MAKE CONTACT TO BRACKET OR BOLTS!