



EDELBROCK TIMING COVER
For use with Small Block Chevy V8s
Part #4240
INSTALLATION INSTRUCTIONS

Please read these instructions carefully before installing your new timing cover. If you have any questions, do not hesitate to contact our **Technical Hotline at: (800) 416-8628** or our Sales line at: (310) 781-2222 from 7:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time.

Installation: Your new cover comes with an 8" diameter timing cover tab, Allen bolts and washers, dampener seal, pan seal, block gasket, and two special water pump gaskets (gaskets give additional clearance from water pump to cover.) Make sure dampener is clean and free of defects on seal area and lubricate with engine oil prior to assembly. Make sure water pump does not come in contact with cover on assembly.

Part #4240
Rev. 8/09 - AJ/mc

©2009 Edelbrock Corporation
Brochure #63-4240



EDELBROCK TIMING COVER
For use with Small Block Chevy V8s
Part #4240
INSTALLATION INSTRUCTIONS

Please read these instructions carefully before installing your new timing cover. If you have any questions, do not hesitate to contact our **Technical Hotline at: (800) 416-8628** or our Sales line at: (310) 781-2222 from 7:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time.

Installation: Your new cover comes with an 8" diameter timing cover tab, Allen bolts and washers, dampener seal, pan seal, block gasket, and two special water pump gaskets (gaskets give additional clearance from water pump to cover.) Make sure dampener is clean and free of defects on seal area and lubricate with engine oil prior to assembly. Make sure water pump does not come in contact with cover on assembly.

Part #4240
Rev. 8/09 - AJ/mc

©2009 Edelbrock Corporation
Brochure #63-4240



EDELBROCK TIMING COVER
For use with Small Block Chevy V8s
Part #4240
INSTALLATION INSTRUCTIONS

Please read these instructions carefully before installing your new timing cover. If you have any questions, do not hesitate to contact our **Technical Hotline at: (800) 416-8628** or our Sales line at: (310) 781-2222 from 7:00 am to 5:00 pm, Monday through Friday, Pacific Standard Time.

Installation: Your new cover comes with an 8" diameter timing cover tab, Allen bolts and washers, dampener seal, pan seal, block gasket, and two special water pump gaskets (gaskets give additional clearance from water pump to cover.) Make sure dampener is clean and free of defects on seal area and lubricate with engine oil prior to assembly. Make sure water pump does not come in contact with cover on assembly.

Part #4240
Rev. 8/09 - AJ/mc

©2009 Edelbrock Corporation
Brochure #63-4240