



**Elite Breather 90° side mounting  
Part #4201 & #4211  
INSTALLATION INSTRUCTIONS**

**INSTALLATION INSTRUCTIONS:**

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation  
Part #4201 & 4211

**Edelbrock Corporation**  
**2700 California St., Torrance, CA 90503**  
**Tech Line: (800) 416-8628; Office: (310) 781-2222**  
**E-Mail: Edelbrock@Edelbrock.com**

Rev. 1/09 - AJ/mc  
Brochure #63-4201



**Elite Breather 90° side mounting  
Part #4201 & #4211  
INSTALLATION INSTRUCTIONS**

**INSTALLATION INSTRUCTIONS:**

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation  
Part #4201 & 4211

**Edelbrock Corporation**  
**2700 California St., Torrance, CA 90503**  
**Tech Line: (800) 416-8628; Office: (310) 781-2222**  
**E-Mail: Edelbrock@Edelbrock.com**

Rev. 1/09 - AJ/mc  
Brochure #63-4201



**Elite Breather 90° side mounting  
Part #4201 & #4211  
INSTALLATION INSTRUCTIONS**

**INSTALLATION INSTRUCTIONS:**

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation  
Part #4201 & 4211

**Edelbrock Corporation**  
**2700 California St., Torrance, CA 90503**  
**Tech Line: (800) 416-8628; Office: (310) 781-2222**  
**E-Mail: Edelbrock@Edelbrock.com**

Rev. 1/09 - AJ/mc  
Brochure #63-4201



**Elite Breather 90° side mounting  
Part #4201 & #4211  
INSTALLATION INSTRUCTIONS**

**INSTALLATION INSTRUCTIONS:**

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation  
Part #4201 & 4211

**Edelbrock Corporation**  
**2700 California St., Torrance, CA 90503**  
**Tech Line: (800) 416-8628; Office: (310) 781-2222**  
**E-Mail: Edelbrock@Edelbrock.com**

Rev. 1/09 - AJ/mc  
Brochure #63-4201